



Coil ECU Reboot

Once your new coils and leads you may find it beneficial to carry out the procedure below as it will reset the cars ECU (the same as rebooting a computer that's been playing up)

- 1. Disconnect battery & leave for a minute.**
- 2. Reconnect battery and turn to ignition II so the dash lights are on,**
- 3. Pump the brake 20 times**
- 4. Turn the key forward to start the engine and leave to run for 5 minutes on idle,
You may hear the revs rise and fall but this is O/K**
- 5. Turn engine off**
- 6. Restart engine, let run for 2 minutes turning the steering from lock to lock two or three times to reset DSC and steering.**